## **Pulling Eye Removal Instructions**

After the cable assembly has been pulled into place, the technician can remove the pulling eye.

Carefully cut at the silver line just below the tape covered knot below the colored pulling loop. Be sure that all the connectors have stayed in position so that none of them are mistakenly cut off.



At the other end, where the mesh is taped to the cable jacket, you will see a short white string. Grasp this string with needle nose pliers and use it like a rip cord to open the tape. It can be helpful to wrap the string around the pliers.



First pull toward the jacket to split and remove the outer tape and then remove the mesh. Pull the rip cord again in the opposite direction to split the inner layer of tape to reveal the braided and knotted Kevlar. Once the inner layer of tape is removed, carefully remove the Kevlar and any other protective material such as sticky foam, if present. Care must be taken to not break the fibers by pulling on or harshly bending the fibers.

If you have any questions call technical support at Fiberdyne Labs, 800-894-9694.

(800) 894-9694

I FIBERDYNE LABS, INC.

Sales@fiberdyne.com